

# Assembly Instructions

5. Secure the Side Rails to the Upright as shown.

- a) Insert top of side rail into the rail clamp located on the upright.
- b) Tighten upright rail clamp with allen wrench provided. Leave the clamp slightly loose until the bottom of the side rails are secured.
- c) Secure bottom of side rails to frame using hardware provided as shown. Tighten bolts thoroughly. Re-tighten top rail clamps.

